

IMPORTANT FILING NOTICE

The contents for this envelope will be found among the last folders in this complete set of folders . . . unless it has been purchased as part of a complete volume of PHOTOFACTS assembled in a DeLuxe Binder.

Merely insert the corresponding folder on this model in this envelope to retain proper filing and indexing order.



MODEL TV30

**FADA MODELS
TV30, 799, 899, 930, 940**


HOWARD W. SAMS & CO., INC. • 2924 East Washington Street • Indianapolis 1, Indiana

"The listing of any available replacement part herein does not constitute in any case a recommendation, warranty or guaranty by Howard W. Sams & Co., Inc., as to the quality and suitability of such replacement part. The numbers of these parts have been compiled from information furnished to Howard W. Sams & Co., Inc., by the manufacturers of the particular type of replacement part listed." "Reproduction

or use, without express permission, of editorial or pictorial content, in any manner, is prohibited. No patent liability is assumed with respect to the use of the information contained herein. Copyright 1949 by Howard W. Sams & Co., Inc., Indianapolis, Indiana, U.S.A. Copyright under International Copyright Union. All rights reserved under Inter-American Copyright Union (1910) by Howard W. Sams & Co., Inc."

Printed in U. S. of America

Date 10/49 Set No. 74—Folder No. 3



BRIGHTNESS

HORIZ.
VERT.
HOLD

VOLUME
CONTROL
OFF-ON-SW.
CONTRAST

CHANNEL
SELECTOR
FINE
TUNING

FADA MODELS
TV30, 799, 899, 930, 940

FADA MODEL TV-30

TRADE NAME Fada, Models TV-30, 799, 899, 930, and 940
MANUFACTURER Fada Radio and Electric Co., Inc., 525 Main St., Belleville, New Jersey
TYPE SET Television Receiver
TUBES Thirty

POWER SUPPLY 105-125 Volts 60 cycle AC
TUNING RANGE—Channels 2 thru 13

RATING: 2.5 Amp. @ 117 Volts AC

INDEX


Alignment Instructions	6,7	Photographs (continued)	3
Block Diagram	13	Chassis-top view	
Disassembly Instructions	20	RF Tuner	10
Horizontal Oscillator Alignment	20	Resistor Identification	11,18
Linearity Adjustments	20	Trans., Inductor and Alignment Identification	4,9
Parts List and Description	14,15,16	RF Oscillator Alignment Points	19
Photographs		Schematic	2
Cabinet-rear view	19	Tube Placement Chart	5
Capacitor Identification	12,17	Voltage and Resistance Measurements	8


HOWARD W. SAMS & CO., INC. • Indianapolis 7, Indiana

"The listing of any available replacement part herein does not constitute in any case a recommendation, warranty or guaranty by Howard W. Sams & Co., Inc., as to the quality and suitability of such replacement part. The numbers of these parts have been compiled from information furnished to Howard W. Sams & Co., Inc., by the manufacturers of the particular type of replacement part listed."
 "Reproduction or use, without express permission, of editorial or pictorial con-


tent, in any manner, is prohibited. No patent liability is assumed with respect to the use of the information contained herein. Copyright 1949 by Howard W. Sams & Co., Inc., Indianapolis 7, Indiana, U. S. of America. Copyright under International Copyright Union. All rights reserved under Inter-American Copyright Union (1910) by Howard W. Sams & Co., Inc." Printed in U. S. of America

DATE 10/49 SET #74 FOLDER 3






CHASSIS TOP VIEW




CHASSIS BOTTOM VIEW-TRANS., INDUCTOR AND ALIGNMENT IDENTIFICATION

FADA MODELS
TV30, 799, 899, 930, 940

TUBE PLACEMENT CHART



TOP VIEW



BOTTOM VIEW

ALIGNMENT INSTRUCTIONS

PRE - ALIGNMENT INSTRUCTIONS—READ CAREFULLY BEFORE ATTEMPTING ALIGNMENT

If alignment is performed with picture tube removed, remove V22 from its socket to disable the high voltage supply.

The oscillator tube (V3) should be removed when performing IF adjustments. Use insulated alignment screwdriver for adjusting.

VIDEO IF ALIGNMENT

If receiver is badly misaligned making it impossible to get sufficient reading on VTVM with the signal being fed to the ant. terminals, signal may be fed to the mixer grid. This point is accessible through the hole in the chassis on right side of tuner (Point $\diamond$).

DUMMY ANTENNA	SIGNAL GENERATOR COUPLING	SIGNAL GENERATOR FREQUENCY	CHANNEL	CONNECT VTVM	ADJUST	REMARKS
1			9	DC probe to junction of R40 and R41. Common to chassis.		Set contrast control to give a -3 volt reading. Leave at this setting during entire IF Alignment procedure.
2 Direct	To ant. terminals. (See prealignment notes)	19.75MC	9	DC probe to point $\diamond$. Common to chassis.	A1	Adjust for <u>minimum</u> deflection.
3 Direct	"	21.25MC	9	"	A2	"
4 Direct	"	21.25MC	9	"	A3	"
5 Direct	"	27.25MC	9	"	A4	"
6 Direct	"	21.8MC	9	"	A5	Adjust for maximum deflection.
7 Direct	"	25.3MC	9	"	A6	"
8 Direct	"	22.3MC	9	"	A7	"
9 Direct	"	25.2MC	9	"	A8	"
10 Direct	"	23.4MC	9	"	A9	Adjust for maximum deflection. If A7 required adjustment in Step 8 repeat Step 2. If FM signal gen. is not available continue with Step 12.

OVERALL VIDEO IF ALIGNMENT

Connect the synchronized sweep voltage from the signal generator to the horizontal amplifier in the scope for horizontal deflection.

The waveforms shown may be inverted depending on the number of amplifying stages in the vertical amplifier in the scope being used.

DUMMY ANTENNA	SIGNAL GENERATOR COUPLING	SWEEP GENERATOR FREQUENCY	MARKER GENERATOR FREQUENCY	CHANNEL	CONNECT SCOPE	ADJUST	REMARKS
11 5000 MMF	To dummy mixer tube. (See Fig. 6).	24MC (10MC sweep)	See Fig. 4.	9	Vert. Amp. to Point $\diamond$. Ground to chassis.	A5, A6, A7, A8, A9	Make slight adjustments if necessary to obtain response curve per Fig. 4. If considerable adjustment is required the traps must be realigned.

SOUND IF ALIGNMENT USING VTVM


Do not remove the shield covering the discriminator tube socket during Step 12. Fashion hook on 1 Megohm resistor and make connection to Point $\diamond$ through alignment hole in shield.

DUMMY ANTENNA	SIGNAL GENERATOR COUPLING	SIGNAL GENERATOR FREQUENCY	CHANNEL	CONNECT VTVM	ADJUST	REMARKS
12 5000MMF	High side to Pin #1 of 3rd Sound IF (V13). Low side to chassis.	21.25MC	9	DC probe to Point $\diamond$ in series with 1 Meg. Common to chassis.	A10	Detune All. Adjust A10 for maximum deflection.
13 5000MMF	"	"	9	DC probe to Point $\diamond$. Common to chassis.	All	Adjust for zero reading. A positive or negative reading is obtained on either side of correct setting.
14 5000MMF	High side to Pin #1 of 2nd Sound IF (V12). Low side to chassis.	"	9	DC probe to Point $\diamond$. Common to chassis.	A12, A13	Adjust for maximum deflection.
15 5000MMF	High side to tap on trap winding of L7. Low side to chassis.	"	9	"	A14, A15	"

SOUND IF ALIGNMENT USING FM SIGNAL GENERATOR AND OSCILLOSCOPE

DUMMY ANTENNA	SIGNAL GENERATOR COUPLING	SWEEP GENERATOR FREQUENCY	MARKER GENERATOR FREQUENCY	CHANNEL	CONNECT SCOPE	ADJUST	REMARKS
12 5000MMF	High side to Pin 1 of 3rd Sound IF (V13). Low side to chassis.	21.25MC (600KC sweep)	21.25MC	9	Vertical amp. to Point $\diamond$. Ground to chassis.	A10, A11	Adjust for maximum amplitude of peaks and straightness of diagonal line with marker at center of line.
13 5000MMF	High side to Pin 1 of 2nd Sound IF (V12). Low side to chassis.	"	"	9	Vert. amp. to Point $\diamond$ in series with 33K Ω . Ground to chassis.	A12, A13	Adjust for maximum amplitude and symmetry per Fig. 2.
14 5000MMF	High side to tap on trap winding of L7. Low side to chassis.	"	"	9	"	A14, A15	Adjust for maximum amplitude and symmetry per Fig. 3. Continue with Step 16.

DUMMY MIXER TUBE



CAREFULLY BEND PIN 7 AT RIGHT ANGLE. CONNECT PINS 5 & 6 TO PIN 4 WHICH IS GROUNDED AT THE SOCKET. CONNECT OTHER COMPONENTS AS SHOWN.




FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5

RF & MIXER LINE ALIGNMENT

On those models having the RF Grid returned to the contrast control it is necessary to set the bias at -1.5 volts. Connect D2 probe of VTVM to pin 5 or 6 of 1st AF Tube (V15), common to chassis and set contrast control for reading of -1.5 volts.
The signal generator output should be terminated with a resistance equal to its output impedance (usually 50 ohms).
These adjustments are usually very stable and alignment should not be attempted unless they are known to be out of alignment.

DUMMY ANTENNA	SIGNAL GENERATOR COUPLING	SWEEP GENERATOR FREQUENCY	MARKER GENERATOR FREQUENCY	CHANNEL	CONNECT SCOPE	ADJUST	REMARKS
16 120Ω carbon res. in series with each lead	To ant. terminals.	177MC (10MC sweep)	175.25MC and 179.75MC	7	Vert. amp. to Point $\diamond$ in series with 10KΩ. Ground to chassis.	A16,A17, A18,A19	Adjust for approx. flat top response per Fig. 5 with markers above 70%.
17 "	"	183MC (10MC sweep)	181.25MC and 185.75MC	8	"	"	Check for response curve per Fig. 5.
18 "	"	189MC (10MC sweep)	187.25MC and 191.75MC	9	"	"	"
19 "	"	195MC (10MC sweep)	193.25MC and 197.75MC	10	"	"	"
20 "	"	201MC (10MC sweep)	199.25MC and 203.75MC	11	"	"	"
21 "	"	207MC (10MC sweep)	205.25MC and 209.75MC	12	"	"	"
22 "	"	213MC (10MC sweep)	211.25MC and 215.75MC	13	"	"	"

If markers are below 70% on any channel make slight adjustment of A16, A17, A18 and A19 with channel selector on that channel. Recheck the other low band channels.

DUMMY ANTENNA	SIGNAL GENERATOR COUPLING	SIGNAL GENERATOR FREQUENCY	MARKER GENERATOR FREQUENCY	CHANNEL	CONNECT SCOPE	ADJUST	REMARKS
23 120Ω carbon res. in series with each lead	To ant. terminals.	85MC (10MC sweep)	83.25MC and 87.75MC	6	Vert. amp. to Point $\diamond$ in series with 10KΩ. Ground to chassis.	A20,A21, A22,A23	Adjust for approx. flat top response per Fig. 5 with markers above 70%.
24 "	"	79MC (10MC sweep)	77.25MC and 81.75MC	5	"	"	Check for response curve per Fig. 5.
25 "	"	69MC (10MC sweep)	67.25MC and 71.75MC	4	"	"	"
26 "	"	63MC (10MC sweep)	61.25MC and 65.75MC	3	"	"	"
27 "	"	57MC (10MC sweep)	55.25MC and 59.75MC	2	"	"	"

If markers are below 70% on any channel make slight adjustments of A20, A21, A22 and A23 with channel selector on that channel. Recheck the other high band channels.

OSCILLATOR ALIGNMENT

DUMMY ANTENNA	SIGNAL GENERATOR COUPLING	SWEEP GENERATOR FREQUENCY	CHANNEL	CONNECT VTVM	ADJUST	REMARKS
28 2 - 120Ω carbon res.	To ant. terminals.	215.75MC	13	DC probe to Point $\diamond$. Common to chassis.	A24,A25	Adjust for zero reading. A positive and negative reading is obtained on either side of correct setting. Keep A24 and A25 slugs at approx. the same relative setting.
29 "	"	209.75MC	12	"	A26	Adjust for zero reading as above.
30 "	"	203.75MC	11	"	A27	"
31 "	"	197.75MC	10	"	A28	"
32 "	"	191.75MC	9	"	A29	"
33 "	"	185.75MC	8	"	A30	"
34 "	"	179.75MC	7	"	A31	"
35 "	"	173.75MC	6	"	A32,A33	Adjust for zero reading keeping A32 and A33 slugs at approx. the same relative position.
36 "	"	167.75MC	5	"	A34	Adjust for zero reading.
37 "	"	161.75MC	4	"	A35	"
38 "	"	155.75MC	3	"	A36	"
39 "	"	149.75MC	2	"	A37	"

MIXER GRID TRAP ADJUSTMENT

- Match the output of the signal generator (usually 50Ω carbon resistor across the gen. output and 120Ω carbon resistors in each lead) and connect to receiver antenna terminals.
 - Connect oscilloscope to Point $\diamond$ through 10KΩ.
 - Shunt 1st Video IF Grid to ground with 1000 MMF cap. using shortest possible leads.
 - Loosely couple marker generator to antenna terminals.
 - Turn channel switch and marker generator through low frequency channels and observe response of each channel.
 - Select channel that is essentially flat with sound and picture markers at 80% or more on the response curve.
 - Remove shunt on 1st IF Grid and shunt the 2nd Video IF Grid to ground.
 - Adjust A38 (rear of tuner) for RF response similar to one selected with 1st IF Grid shunted.
- NOTE: In later productions A38 is a fixed capacitor (C18). In those receivers this step may be followed as a check that correct mixer operation is obtained.

WAVE TRAP ADJUSTMENT

Wave traps A39 and A40 are used for specific types of interference and their alignment will depend upon the type encountered.
With the receiver tuned to the channel having the interference, set fine tuning control until maximum interference is received. Adjust A39 and A40 for minimum interference in the picture and sound keeping the cores at approximately the same relative position. Then turn one core 1/2 turn and adjust the other for minimum interference.

TV30, 799, 899, 930, 940

VOLTAGE AND RESISTANCE MEASUREMENTS

VOLTAGE READINGS

Item	Tube	Pin 1	Pin 2	Pin 3	Pin 4	Pin 5	Pin 6	Pin 7	Pin 8	Cap
V 1	6J6	50VDC	50VDC	6.2VAC	OV.	-2VDC	-2VDC	OV.	-	-
V 2	6J6	95VDC	95VDC	6.2VAC	OV.	-2VDC	-3.1VDC	OV.	-	-
V 3	6J6	55VDC	55VDC	6.2VAC	OV.	-5.4VDC	-5.2VDC	.2VDC	-	-
V 4	6AG5	OV.	OV.	OV.	6.2VAC	95VDC	95VDC	.3VDC	-	-
V 5	6AG5	-8VDC	.2VDC	6.2VAC	OV.	98VDC	98VDC	.2VDC	-	-
V 6	6AG5	-8VDC	.2VDC	6.2VAC	OV.	93VDC	105VDC	.2VDC	-	-
V 7	6AG5	OV.	1VDC	6.2VAC	OV.	85VDC	110VDC	1VDC	-	-
V 8	6AL5	OV.	OV.	6.2VAC	OV.	.7VDC	OV.	OV.	-	-
V 9	6AU6	-6VDC	OV.	OV.	6.2VAC	255VDC	117VDC	OV.	-	-
V 10	6K6GT	OV.	OV.	92VDC	117VDC	-2VDC	OV.	6.2VAC	2.8VDC	-
V 11	6BA6	OV.	OV.	OV.	6.2VAC	103VDC	103VDC	1.4VDC	-	-
V 12	6BA6	OV.	OV.	OV.	6.2VAC	107VDC	105VDC	1VDC	-	-
V 13	6AU6	-3VDC	OV.	OV.	6.2VAC	45VDC	45VDC	OV.	-	-
V 14	6AL5	2.2VDC	-4VDC	4.9VAC	OV.	OV.	OV.	-7VDC	-	-
V 15	6AT6	-4VDC	OV.	OV.	6.2VAC	-8VDC	-8VDC	75VDC	-	-
V 16	6K6GT	OV.	6.2VAC	240VDC	250VDC	-9VDC	OV.	OV.	OV.	-
V 17	6SK7	OV.	OV.	OV.	-8VDC	OV.	108VDC	6.2VAC	208VDC	-
V 18	6SH7	OV.	OV.	OV.	-2.6VDC	OV.	117VDC	6.2VAC	115VDC	-
V 19	6SN7GT	-1.4VDC	77VDC	OV.	-120VDC	-37VDC	-90VDC	6.2VAC	OV.	-
V 20	6AL5	-8VDC	-5.8VDC	OV.	4.9VAC	-2VDC	OV.	-6.5VDC	-	-
V 21	6AC7	OV.	OV.	OV.	-9VDC	OV.	105VDC	6.2VAC	190VDC	-
V 22	6K6GT	OV.	OV.	170VDC	210VDC	-18.5VDC	340VDC	6.2VAC	.3VDC	-
V 23	6BQ6-G	OV.	6.2VAC	-82VDC	OV.	-94VDC	OV.	OV.	165VDC	#
V 24	5Y4G	OV.	350VDC	OV.	290VDC	OV.	290VDC	OV.	350VDC	-
V 25	6J5	OV.	OV.	-3.2VDC	-90VDC	-115VDC	-85VDC	6.2VAC	-90VDC	-
V 26	6K6GT	OV.	6.2VAC	187VDC	187VDC	-55VDC	-67VDC	OV.	-50VDC	-
V 27	1B3GT	#DO NOT MEASURE.								
V 28	5U4G	OV.	350VDC	OV.	360VAC	OV.	360VAC	OV.	350VDC	-
V 29	5U4G	OV.	350VDC	OV.	360VAC	OV.	360VAC	OV.	350VDC	-
V 30	10BP4	OV.	1VDC	PIN 10 260VDC	PIN 11 OV.	PIN 12 6.2VAC				


#DO NOT MEASURE.

RESISTANCE READINGS


Item	Tube	Pin 1	Pin 2	Pin 3	Pin 4	Pin 5	Pin 6	Pin 7	Pin 8	Cap
V 1	6J6	6KΩ*	6KΩ*	.1Ω	Ω	1KΩ	1KΩ	Ω	-	-
V 2	6J6	3KΩ*	3KΩ*	.1Ω	Ω	1 Meg.	1 Meg.	Ω	-	-
V 3	6J6	6.8KΩ*	6.8KΩ*	.1Ω	Ω	100KΩ	100KΩ	47Ω	-	-
V 4	6AG5	17KΩ	40Ω	Ω	.1Ω	3KΩ*	3KΩ*	40Ω	-	-
V 5	6AG5	16KΩ	40Ω	.1Ω	Ω	3KΩ*	3KΩ*	40Ω	-	-
V 6	6AG5	10KΩ	40Ω	.1Ω	Ω	5KΩ*	2.5KΩ*	40Ω	-	-
V 7	6AG5	.2Ω	150Ω	.1Ω	Ω	7.5KΩ*	2.5KΩ*	150Ω	-	-
V 8	6AL5	.2Ω	100KΩ	.1Ω	Ω	1.2 Meg.	Ω	4KΩ	-	-
V 9	6AU6	500KΩ	Ω	Ω	.1Ω	9KΩ*	1.4KΩ*	Ω	-	-
V 10	6K6GT	Ω	Ω	4.5KΩ*	1.4KΩ*	500KΩ	INF.	.1Ω	330Ω	-
V 11	6BA6	.1Ω	Ω	Ω	.1Ω	2.5KΩ*	2.5KΩ*	100Ω	-	-
V 12	6BA6	500KΩ	Ω	.1Ω	Ω	2.5KΩ*	4.2KΩ*	100Ω	-	-
V 13	6AU6	20KΩ	Ω	Ω	.1Ω	7KΩ*	7KΩ*	Ω	-	-
V 14	6AL5	200KΩ	100KΩ	.1Ω	Ω	Ω	Ω	100KΩ	-	-
V 15	6AT6	10 Meg.	Ω	Ω	.1Ω	10KΩ	10KΩ	330KΩ*	-	-
V 16	6K6GT	INF.	.1Ω	1.5KΩ*	1KΩ*	250KΩ	260KΩ	Ω	Ω	-
V 17	6SK7	Ω	Ω	Ω	900KΩ	Ω	2.2KΩ*	.1Ω	9KΩ*	-
V 18	6SH7	Ω	Ω	Ω	900KΩ	Ω	1.4KΩ*	.1Ω	7.5KΩ*	-
V 19	6SN7GT	1.2 Meg.	7KΩ*	Ω	230KΩ	650KΩ*	450Ω	.1Ω	Ω	-
V 20	6AL5	900KΩ	1.5 Meg.	Ω	.1Ω	12Ω	Ω	1.5 Meg.	-	-
V 21	6AC7	Ω	Ω	Ω	1.4 Meg.	10Ω	18KΩ*	.1Ω	20KΩ*	-
V 22	6K6GT	INF.	Ω	5KΩ*	10KΩ*	25KΩ	5.8KΩ*	.1Ω	10Ω	-
V 23	6BQ6-G	INF.	.1Ω	540Ω	INF.	450KΩ	INF.	Ω	9.5KΩ*	6KΩ*
V 24	5Y4G	INF.	5.5KΩ*	INF.	50Ω*	INF.	50Ω*	INF.	5.5KΩ*	-
V 25	6J5	Ω	Ω	250KΩ*	65KΩ	1.5 Meg.	65KΩ	.1Ω	450Ω	-
V 26	6K6GT	INF.	.1Ω	10KΩ*	10KΩ*	2.5 Meg.	2500Ω	Ω	2KΩ	-
V 27	1B3GT	INF.	INF.	INF.	INF.	INF.	INF.	INF.	INF.	6KΩ*
V 28	5U4G	INF.	5.5KΩ	INF.	460Ω	INF.	460Ω	INF.	5.5KΩ	-
V 29	5U4G	INF.	5.5KΩ	INF.	460Ω	INF.	460Ω	INF.	5.5KΩ	-
V 30	10BP4	Ω	1.3 Meg.	PIN #10 150KΩ*	PIN #11 Ω	PIN #12 .1Ω				

*MEASURED FROM PIN 8 OF V28.


1. DC Voltage measurements are at 20,000 ohms per volt; AC Voltages measured at 1000 ohms.
2. Socket connections are shown as bottom views.
3. Measured values are from socket pin to common negative unless otherwise stated.
4. Line voltage maintained at 117 volts for voltage readings.
5. Front panels controls set at maximum.
6. Where readings may vary according to the setting of the service controls, both minimum and maximum readings are given.




RF TUNER - RIGHT SIDE



RF TUNER - LEFT SIDE




CHASSIS BOTTOM VIEW-RESISTOR IDENTIFICATION



CHASSIS BOTTOM VIEW - CAPACITOR IDENTIFICATION

FADA MODELS
TV30, 799, 899, 930, 940



BLOCK DIAGRAM

PARTS LIST AND DESCRIPTIONS

CAPACITORS (CONT.)

RESISTORS (CONT.)

TUBES (SYLVANIA or Equivalent)

ITEM No.	USE	REPLACEMENT DATA		RMA BASE TYPE	NOTES
		FADA PART No.	STANDARD REPLACEMENT		
V1	RF Amp.	6J6	6J6	7BF	
V2	Mixer	6J6	6J6	7BF	
V3	Oscillator	6J6	6J6	7BF	
V4	1st V. IF Amp.	6AG5	6AG5	7BD	
V5	2nd V. IF Amp.	6AG5	6AG5	7BD	
V6	3rd V. IF Amp.	6AG5	6AG5	7BD	
V7	4th V. IF Amp.	6AG5	6AG5	7BD	
V8	Video Det., DC Res.	6AL5	6AL5	6BT	
V9	Video Amp.	6AU6	6AU6	7BK	
V10	Video Output	6K6GT	6K6GT	7S	
V11	1st S. IF Amp.	6BA6	6BA6	7BK	
V12	2nd S. IF Amp.	6BA6	6BA6	7BK	
V13	3rd S. IF Amp.	6AU6	6AU6	7BK	
V14	Sound Disc.	6AL5	6AL5	6BT	
V15	Audio Amp.	6AT6	6AT6	7BT	
V16	Power Output	6K6GT	6K6GT	7S	
V17	1st Sync. Amp.	6SK7	6SK7	8N	
V18	Sync. Sep.	6SH7	6SH7	8BK	
V19	2nd Sync. Amp., Hor. Discharge	6SN7GT	6SN7GT	8BD	
V20	Hor. Sync. Disc.	6AL5	6AL5	6BT	
V21	Hor. React.	6AC7	6AC7	8N	
V22	Hor. Osc.	6K6GT	6K6GT	7S	
V23	Hor. Output	6BG6-G	6BG6-G	5BT	
V24	Damper	5V4G	5V4G	5L	
V25	Vert. Osc., Discharge	6J5	6J5	6Q	
V26	Vert. Output	6K6GT	6K6GT	7S	
V27	HV Rect.	1B3GT	1B3GT	3C	
V28	LV Rect.	5U4G	5U4G	5T	
V29	LV Rect.	5U4G	5U4G	5T	
V30A	Picture Tube	10BP4	10BP4	12D	Used in models TV-30, 799, 899
B	Picture Tube	12LP4	12LP4	12D	Used in Models 930, 940

CAPACITORS

Capacity values given in the rating column are in mfd. for Electrolytic and Paper Capacitors, and in mmfd. for Mica and Ceramic Capacitors.

ITEM No.	RATING		REPLACEMENT DATA				IDENTIFICATION CODES AND INSTALLATION NOTES	
	CAP.	VOLT	FADA PART No.	AEROVOX PART No.	CORNELL-DUBILIER PART No.	ERIE PART No.		SPRAGUE PART No.
C1A	40	450	22.22		UP9C729-3		D14367	▲ Filter
B	10	450						■ Filter
C	80	150						▲ Bias Filter
C2A	40	450	22.23		UP9C897-3		D14648	▲ Filter
B	40	450						■ Filter
C	10	450						▲ Vert. Out. Plate Decoup.
C3A	80	450	22.24		UP9B730-3		D14369	▲ Filter
B	50	50						▲ Vert. Out. Cath.
C4A	40	450	22.25		UP9C731-1		D14370	▲ Filter
B	10	450						■ Low Pass Filter
C	10	350						▲ 2nd Sync. Amp. Plate
C5A	20	450	22.26		UP9B337-1		D14371	▲ Audio Out. Screen
B	80	350						▲ Filter
C6A	250	10	22.27	PRS12/250	UP7B808-4		D14338	■ Filter
B	1000	6		PRS6/1000				▲ Filter
C7	270				GP2K-270			Ant. Coupling
C8	270				GP2K-270			"
C9	1500		17.12		GP2L-0015			RF Bypass
C10	10				NPOK-10			Fixed Trimmer
C11	10				NPOK-10			"
C12	1.5		17.67		NPOK-1.5			RF Neutralizer
C13	1.5		17.67		NPOK-1.5			"
C14	1.68		17.66					RF Coupling
C15	4.7				NPOK-4.7			"
C16	2.2							"
C17	1500		17.12		GP2L-0015			RF Decoupling
C18	270				GP2K-270			RF Bypass
C19	10				GP1K-10			RF Decoupling
C20	1500		17.12		GP2L-0015			"
C21	270	500			GP2K-270			IF Coupling
C22	68				GP1K-68			Fixed Trimmer
C23	1500		17.12		GP2L-0015			Mixer Decoupling
C24	4.7				NPOK-4.7			Osc. Feedback
C25	4.7				NPOK-4.7			"
C26	1500		17.12	1467-0015	1W5D15	GP2L-0015	1FM-215	Fil. Bypass
C27	1500		17.45	1467-0015	1W5D15	GP2L-0015	1FM-215	"
C28	1500		17.45	1467-0015	1W5D15	GP2L-0015	1FM-215	Bias Filter
C29	1500		17.45	1467-0015	1W5D15	GP2L-0015	1FM-215	1st V. IF Decoupling.
C30	1500		17.45	1467-0015	1W5D15	GP2L-0015	1FM-215	1st V. IF Decoupling.
C31	270	500	17.9	1468-0003	5W5T3	GP2K-270	1FM-215	RF Bypass
C32	1500		17.45	1467-0015	1W5D15	GP2L-0015	1FM-215	Video IF Coupling
C33	1500		17.45	1467-0015	1W5D15	GP2L-0015	1FM-215	Bias Filter
C34	1500		17.45	1467-0015	1W5D15	GP2L-0015	1FM-215	2nd V. IF Fil. Byp.
C35	1500		17.45	1467-0015	1W5D15	GP2L-0015	1FM-215	2nd V. IF Decoup.
C36	270	500	17.9	1468-0003	5W5T3	GP2K-270	1FM-215	RF Bypass
C37	1500		17.45	1467-0015	1W5D15	GP2L-0015	1FM-215	Video IF Coupling
C38	25	400	12.16	P488-.25	GT4P25	GP2L-0015	1FM-215	Bias Filter
C39	1500		17.45	1467-0015	1W5D15	GP2L-0015	1FM-215	TC-2
C40	1500		17.45	1467-0015	1W5D15	GP2L-0015	1FM-215	3rd V. IF Fil. Byp.
C41	270	500	17.9	1468-0003	5W5T3	GP2K-270	1FM-215	3rd V. IF Decoupling
C42	1500		17.45	1467-0015	1W5D15	GP2L-0015	1FM-215	Video IF Coupling
C43	1500		17.45	1467-0015	1W5D15	GP2L-0015	1FM-215	RF Bypass
C44	82		17.37			GP2L-0015	1FM-215	4th V. IF Fil. Byp.
C45	1500		17.45	1467-0015	1W5D15	GP2L-0015	1FM-215	4th V. IF Cath.
C46	1500		17.45	1467-0015	1W5D15	GP2L-0015	1FM-215	4th V. IF Decoup.
C47	270	500	17.9	1468-0003	5W5T3	GP2K-270	1FM-215	RF Bypass
C48	1500		17.45	1467-0015	1W5D15	GP2L-0015	1FM-215	Video Coupling
C49	10	500	17.33	1468-00001	5W5Q1	GP1K-10	1FM-215	Video Det. Fil. Byp.
C50	.05	400	12.12	P488-05	GT485		TM-15	RF Filter
C51	.05	400	12.38	P488-05	GT485		TM-15	Video Coupling
C52	.05	400	12.12	P488-05	GT485		TM-15	"
C53	.05	400	12.12	P488-05	GT485		TM-15	"
C54	.25	400	12.16	P488-.25	GT4P25		TC-2	Video Coupling

ITEM No.	RATING CAP. VOLT	REPLACEMENT DATA		ERIE PART No.	SPRAGUE PART No.	IDENTIFICATION CODES AND INSTALLATION NOTES
		FADA PART No.	AEROVOX PART No.			
C55	1500				GP2L-0015	1st S. IF Cath. Byp.
C56	1500				GP2L-0015	1st S. IF Decoupling
C57	.01				GP2-335-01	2nd S. IF Grid Filter
C58	1500				GP2L-0015	2nd S. IF Cath. Byp.
C59	1500				GP2L-0015	2nd S. IF Screen Byp.
C60	1500				GP2L-0015	2nd S. IF Plate Decoupling
C61	51				GP1K-50	3rd S. IF Grid Filter
C62	6500					3rd S. IF Decoupling
C63	270				GP2K-270	De-emphasis
C64	.0025				GP2M-0025	Audio Coupling
C65	.01				GP2-335-01	Tone Compensation
C66	.01				GP2-335-01	Audio Coupling
C67	.0025				GP2M-0025	Audio Plate Bypass
C68	.005				GP2M-005	Audio Coupling
C69	.005				GP2M-005	Output Plate Bypass
C70	.05				GP2K-270	Sync. Coupling
C71	270				GP2K-270	1st Sync. Amp. Plate
C72	.1				GP2K-270	1st Sync. Amp. Plate Decoup.
C73	270					Sync. Coupling
C74	.05					Hor. Sync. Coupling
C75	82					AFC Filter
C76	.004				PX-241	Video Output Cath. Byp.
C77	.01				1FM-35	Fixed Trimmer
C78	.015					AFC Filter
C79	.05					Phase Shifter
C80	.015					AFC Coupling
C82	.004					Hor. Sync. Coupling
C83	.004					H. Osc. Contr. Screen
C84	.05					Hor. Osc. Screen
C85	.05					Differentiator Net.
C86	390					Integrating Net.
C87	.01					"
C88	.001					"
C89	680					"
C90	.05					"
C91	.1					"
C92	.01					"
C93	.002					"
C94	.005					"
C95	.005					"
C96	4700					"
C97	.1					"
C98	.05					"
C99	.035					"
C100	.05					"
C101	.01					"
C102	.01					"
C103	500					"

CONTROLS

ITEM No.	RATING RESISTANCE WATTS	REPLACEMENT DATA		CLAROSTAT PART No.	INSTALLATION NOTES
		FADA PART No.	IRC PART No.		
R1A	1 Meg.	52.22			Volume control tapped @ 200KΩ
B	& 10KΩ				Contrast control (Dual Concentric)
C	Switch				On-Off switch-SPST
R2A	1 Meg.	52.21			Vertical hold (Dual Concentric)
B	& 50KΩ				Horizontal Hold
R3	50KΩ	52.20	Q11-123	M-44-S	Brightness control
R4	20Ω	52.26	W-20	43-20	Horiz. Centering-Center Tap Not Used
R5	20Ω	52.26	W20X10	43-20CT	Vert. Centering-Tapped @ 10Ω
R6	1500Ω	52.27			Focus control
R7A	5000Ω	52.25	Q11-114	AM-19-S	Vert. Linearity
B	Shaft		Not Req.	KSS-3	Attach to R7A Per Instructions
R8	2.5 Meg	52.24			Height control
R9A	20KΩ	52.23	Q11-120	AM-40-S	Peaking
B	Shaft		Not Req.	KSS-3	Attach to R9A Per Instructions

* On Models 930, 940 the Brightness and Focus controls are combined in one dual concentric control - Fada Part No. 52.49

RESISTORS

ITEM No.	RATING RESISTANCE WATTS	REPLACEMENT DATA		IDENTIFICATION CODES
		FADA PART No.	IRC PART No.	
R10	150Ω	32.4		RF Amp. Grid
R11	150Ω	32.4		"
R12	1000Ω	32.8	BTS-1000	Bias Network
R13	4700Ω	32.9	BTS-4700	RF Amp. Plate
R14	4700Ω	32.9	BTS-4700	"
R15	1000Ω	32.8	BTS-1000	RF Amp. Plate Decoupling
R16	1 Meg.	32.23	BTS-1 Meg.	Mixer Grid
R17	4700Ω	32.9	BTS-4700	Osc. Plate
R18	150Ω	32.4		Decoupling
R19	1000Ω	32.8	BTS-1000	Conv. Plate Decoupling
R20	47Ω			Osc. Cathode
R21	100KΩ	32.17	BTS-100K	Osc. Grid
R22	100KΩ	32.17	BTS-100K	Osc. Grid
R23	10KΩ	32.80	BTS-10K-5%	1st Video IF Grid
R24	39Ω	32.64		1st Video IF Cathode
R25	1000Ω	32.8	BTS-1000	IF Contrast Bias Network
R26	150Ω	32.4		Decoupling
R27	1000Ω	32.8	BTS-1000	"
R28	150Ω	32.4		"
R29	680KΩ	32.93	BTS-680K-5%	Voltage Dropping
R30	10KΩ	32.80	BTS-10K-5%	2nd Video IF Grid
R31	1000Ω	32.8	BTS-1000	IF Contrast Bias Network
R32	39Ω	32.64		2nd Video IF Cathode
R33	1000Ω	32.8	BTS-1000	Decoupling
R34	150Ω	32.4		"
R35	4700Ω	32.75	BTS-4700-5%	3rd Video IF Grid
R36	39Ω	32.64		3rd Video IF Cathode
R37	2700Ω	32.57	BTS-2700-5%	3rd Video IF Plate
R38	1000Ω	32.8	BTS-1000	Decoupling
R39	150Ω	32.4		"
R40	8200Ω	32.77	BTS-8200	Contrast Bias Network
R41	18KΩ	32.81	BTS-18K	"

ITEM No.	RATING		REPLACEMENT DATA		IDENTIFICATION CODES
	RESISTANCE	WATTS	FADA PART No.	IRC PART No.	
R42	680Ω	1/2	32.31	BTS-680	" " "
R43	10KΩ	1/2	32.11	BTS-10K	" " "
R44	2700Ω	1/2	32.57	BTS-2700	" " "
R45	150Ω	1/2	32.4		4th Video IF Cathode
R46	5600Ω	1/2	32.76	BTS-5600-5%	4th Video IF Plate
R47	1000Ω	1/2	32.8	BTS-1000	Decoupling
R48	390Ω	1/2	32.73	BTS-3900-5%	Diode Load
R49	470KΩ	1/2	32.92	BTS-470K	1st Video Amp. Grid
R50	3300Ω	1/2	32.32	BTS-3300	1st Video Amp. Plate
R51	6800Ω	1/2	32.10	BTS-6800	" " "
R52	820KΩ	1/2	32.94	BTS-820K-5%	2nd Video Amp. Grid
R53	1.2 Meg.	1/2	32.96	BTS-1.2Meg-5%	Bias Network
R54	330Ω	1/2	32.67		2nd Video Amp. Cathode
R55	3300Ω	1	32.72	BTA-3300	Voltage Dropping
R56	10KΩ	1/2	32.80	BTS-10K	Sync. Isolation
R57	100KΩ	1/2	32.89	BTS-100K	Picture Tube Grid
R58	1 Meg.	1/2	32.33	BTS-1 Meg.	Diode Load
R59	47KΩ	1/2	32.87	BTS-47K	Bias Network
R60	150KΩ	1/2	32.90	BTS-150K	" " "
R61	100Ω	1/2	32.2		1st Sound IF Cathode
R62	1000Ω	1/2	32.8	BTS-1000	1st Sound IF Decoupling
R63	470KΩ	1/2	32.92	BTS-470K	2nd Sound IF Grid
R64	100Ω	1/2	32.2		2nd Sound IF Cathode
R65	3300Ω	1/2	32.32	BTS-3300	2nd Sound IF Screen
R66	1000Ω	1/2	32.8	BTS-1000	2nd Sound IF Cathode
R67	22KΩ	1/2	32.83	BTS-22K	3rd Sound IF Grid
R68	10KΩ	1/2	32.79	BTA-10K	Voltage Dropping
R69	10KΩ	1	32.11	BTS-10K	Bleeder
R70	100KΩ	1/2	32.89	BTS-100K	Diode Load
R71	100KΩ	1/2	32.89	BTS-100K	" " "
R72	22KΩ	1		BTS-22K	De-emphasis
R73	2.2Ω	1	32.61	BW-2.2	Filament Dropping
R74	10 Meg.	1/2	32.99	BTS-10 Meg.	1st Audio Grid
R75	330KΩ	1/2	32.19	BTS-330K	1st Audio Plate
R76	270KΩ	1/2	32.44	BTS-270K	Audio Output Grid
R77	1100Ω	5		AB-1100	Filter See Note 2
R79	6.8 Meg.	1/2	32.46	BTS-6.8 Meg.	Bias Network
R80	1 Meg.	1/2	32.33	BTS-1 Meg.	1st Sync. Amp. Grid
R81	4700Ω	1	32.74	BTA-4700	1st Sync. Amp. Plate
R82	4700Ω	1	32.74	BTA-4700	1st Sync. Amp. Plate
R83	1 Meg.	1/2	32.33	BTS-1 Meg.	Sync. Sep. Grid
R84	4.7 Meg.	1/2	32.98	BTS-4.7 Meg.	Bias Network
R85	6800Ω	1/2	32.10	BTS-6800	1st Sync. Amp. Plate
R86	1 Meg.	1/2	32.10	BTS-1 Meg.	2nd Sync. Amp. Grid
R87	4700Ω	1/2	32.33	BTS-4700	2nd Sync. Amp. Plate
R88	1000Ω	1/2	32.8	BTS-1000	Decoupling
R89	22KΩ	1/2	32.83	BTS-22K	Differentiator
R90	22KΩ	1/2	32.83	BTS-22K	Integrator
R91	8200Ω	1/2	32.77	BTS-8200	"
R92	8200Ω	1/2	32.77	BTS-8200	"
R93	1.5 Meg.	1/2	32.97	BTS-1.5 Meg. -5%	Vert. Osc. Grid
R94	220KΩ	1/2	32.91	BTS-220K	Vert. Osc. Plate
R95	100KΩ	1/2	32.89	BTS-100K	Voltage Divider
R96	2.2 Meg.	1/2	32.34	BTS-2.2 Meg.	"
R97	2.2 Meg.	1/2	32.34	BTS-2.2 Meg.	Vert. Output Grid
R98	56KΩ	1/2	32.88	BTS-56K	Vert. Osc. Plate
R99	8200Ω	1/2	32.78	BTS-8200-5%	Peaking
R100	1800Ω	1/2		BTS-1800	Vert. Output Cathode
R101	10KΩ	1	32.79	BTA-10K	Vert. Output Plate
R102	470KΩ	1/2	32.92	BTS-470K	Diode Load
R103	470KΩ	1/2	32.92	BTS-470K	" " "
R104	1 Meg.	1/2	32.33	BTS-1 Meg.	" " "
R105	470KΩ	1/2	32.92	BTS-470K	AFC Grid
R106	560Ω	1/2	32.68	BTS-560	AFC Grid Current Limiting
R107	10Ω	1/2	32.63		AFC Cathode
R108	27KΩ	1	32.65	BTA-27K	Bleeder
R109	18KΩ	1	32.66	BTA-18K	AFC Screen Dropping
R110	47KΩ	1	32.15	BTA-47K-5%	AFC Plate
R111	39KΩ	1	32.66	BTA-39K-5%	AFC Plate
R112	27KΩ	1	32.84	BTS-27K	Horiz. Osc. Grid
R113	10KΩ	1	32.79	BTA-10K	Horiz. Osc. Screen
R114	5000Ω	5	117.18	AB-5000	Horiz. Osc. Plate
R115	6800Ω	1/2	32.10	BTS-6800	Differentiator
R116	220KΩ	1/2	32.91	BTS-220K	Horiz. Discharge Grid
R117	690KΩ	1/2	32.93	BTS-690K-5%	Horiz. Discharge Plate
R118	6800Ω	1/2	32.10	BTS-6800	Peaking
R119	470KΩ	1/2	32.92	BTS-470K	Horiz. Output Grid
R120	100Ω	1	32.53		Horiz. Output Cathode
R121	22KΩ	1	32.13	BTA-22K	Horiz. Output Screen
R122	18KΩ	1	32.62	BTA-18K	" " "
R123	6300Ω	50	117.19		Damping See Note 1
R124	1 Meg.	1	32.95	BTA-1 Meg.	High Volt. Filter
R125	1800Ω	1	32.69	BTA-1800	Focus Coil Shunt
R126	270Ω	2	32.66	BW-2-270	" " "
R127A	1360Ω	17	117.20		Bleeder Network
B	230Ω	10			" " "
R128A	6750Ω	3.2	117.21		" " "
B	12Ω				" " "
C	93Ω	4			" " "
R130	3.3Ω	1/2	32.62	BW-3.3-5%	High Voltage Rectifier Filament
R131	10KΩ	1/2	32.11	BTS-10K	Mixer Grid Coil Shunt
R132	150KΩ	1/2	32.90	BTS-150K	ACC. Anode Dropping
R133	27KΩ	1/2	32.84	BTS-27K	Tone Compensation

PARTS LIST AND DESCRIPTIONS (Continued)

TRANSFORMER (POWER)

ITEM No.	RATING				REPLACEMENT DATA			
	PRI.	SEC. 1	SEC. 2	SEC. 3	FADA PART No.	STANCOR PART No.	CHICAGO PART No.	MERIT PART No.
T1	117VAC @ 2.5A	670VAC @ 300MA	12VAC @ 5.1A	5VAC @ 6A SEC. 4 5VAC @ 2A	42.12	P-8152	TP-365	P-3061

TRANSFORMER (SWEEP CIRCUITS)

ITEM No.	RATING		REPLACEMENT DATA				NOTES
	DC RESISTANCE		FADA PART No.	STANCOR PART No.	CHICAGO PART No.	MERIT PART No.	
	PRI.	SEC.					
T2	165Ω	1310Ω	42.15	A-8121	TB0-1	A-4000	Vert. Block. Osc. Trans.
T3	600Ω	6.5Ω	42.14	A-8115	TS0-1	A-3035	Vert. Output Trans.
T4	37Ω	35Ω	37.104				Hor. Sync. Disc. Trans.
		tapped @ 9.5Ω					
T5	420Ω	10.6Ω	42.103				Hor. Output Trans.
	tapped @ 180Ω	@ .6Ω					
		SEC. 2					
		0Ω					
T6	247Ω		37.102	FC-10			Focus Coil
T8A	68Ω		37.101	DY-1			Vert. Deflection Yoke
B	14Ω						Hor. Deflection York

TRANSFORMER (AUDIO OUTPUT)

ITEM No.	RATING		REPLACEMENT DATA				INSTALLATION NOTES
	DC RES.		FADA PART No.	STANCOR PART No.	CHICAGO PART No.	MERIT PART No.	
	PRI.	SEC.					
T9	7300Ω	3.2Ω	480Ω	.7Ω	A-3878	RO-9	A-2931

SPEAKER

ITEM No.	RATING		REPLACEMENT DATA			NOTES
	FIELD RES.	V. C. IMP.	FADA PART No.	JENSEN PART No.	QUAM PART No.	
SPI	PM	3.2Ω				

FILTER CHOKE


ITEM No.	RATINGS			REPLACEMENT DATA				INSTALLATION NOTES
	TOTAL DIRECT CURRENT	D. C. RESISTANCE	INDUCTANCE (0 CURRENT 1000 μ)	FADA PART No.	STANCOR PART No.	CHICAGO PART No.	MERIT PART No.	
L1	300MA	50Ω	3 Henries		C-2326*	TR-3300	C-2991	* Redrill new mounting hole.

COILS (RF-IF)


ITEM No.	USE	DC RES.		REPLACEMENT DATA		NOTES
		PRI.	SEC.	FADA PART No.	MEISSNER PART No.	
L2	Ant. Trans.	0Ω				Part of tuner assy.
L3	Interferen- ce Trap	0Ω				" " " "
L4	"	0Ω				" " " "
L5	Fil. Choke	0Ω		37.89		" " " "
L6	Mixer Grid	.1Ω				" " " "
L7	1st Video			37.96		
	IF & Sound					
	Trap	.2Ω		37.89		" " " "
L8	Fil. Choke	0Ω				
L9	2nd Video	.2Ω	0Ω	37.97		
	IF	0Ω		37.89		
L10	Fil. Choke	0Ω				
L11	3rd Video	.2Ω	0Ω	37.99		
	IF	0Ω		37.89		
L12	Fil. Choke	.2Ω		37.100		
L13	4th Video	.1Ω		37.198		
	IF	0Ω		37.89		
L14	Sound Trap	.1Ω				
L15	Fil. Choke	0Ω		37.89		
L16	5th Video	.1Ω				
	IF	0Ω		37.89		
L17	Fil. Choke	6Ω				Wound on 39KΩ resistor, 180 Microhenry.
L18	Peaking	8Ω				250 Microhenry
L19	Peaking	5Ω				Wound on 22KΩ resistor, 120 Microhenry.
L20	Peaking	4Ω				93 Microhenry
L21	Peaking	5Ω				Wound on 22KΩ resistor, 120 Microhenry
L22	Peaking	4Ω				93 Microhenry
L23	Peaking	.1Ω	0Ω	37.94		
L24	1st Sound	.1Ω	0Ω	37.94		
L25	2nd Sound	0Ω	0Ω	37.95		
L26	Sound Disc.	.6Ω		37.106		
L27	Trans.	37Ω		37.105		
L28	Hor. Width Control					
	Hor. Line-arity Cont.					

MISCELLANEOUS

ITEM No.	PART NAME	FADA PART No.	NOTES
M2	Fuse	42.21	AGC 1/4 Amp.
M3	Tuner Assy.	92.115	Complete unit
M4	Power Cord		
M5	Receptacle		Power Interlock Plug
M6	Terminal Board	152.28	(3 Terminals with Link)
M7	Terminal Board	152.27	Antenna (2 Terminals)



RF OSCILLATOR ALIGNMENT POINTS



CABINET-REAR VIEW

HORIZONTAL OSCILLATOR ALIGNMENT

HORIZONTAL OSCILLATOR ALIGNMENT CHECK:

While receiving a television signal turn the horizontal hold control fully counter-clockwise. Remove the picture momentarily by turning the contrast control fully counter-clockwise and then return it to its normal operating position. The picture should pull back into synchronization.

Now turn the horizontal hold control fully clockwise. Remove the picture momentarily by turning the contrast control fully counter-clockwise and then return to its normal operating position. The picture should pull back into synchronization.

If receiver synchronizes properly under these checks it is not necessary to align the horizontal oscillator. However, if the picture is not normal or stable, the horizontal oscillator must be aligned.

SLIGHT RETOUCH ALIGNMENT

If the receiver failed in the above check at either extreme of the hold control, it may be possible to align the horizontal oscillator by making slight adjustments.

Tune in a TV station and adjust fine tuning for best sound quality. Adjust vertical hold control to vertically synchronize the picture. Adjust the contrast control to slightly less than normal. Turn the horizontal hold control to the extreme position in which the oscillator falls out of synchronization. Momentarily remove the signal. Adjust B_2 (rear of chassis) until the oscillator pulls into synchronization. Check hold and pull-in as outlined above.

COMPLETE ALIGNMENT

Tune in a TV station for the best sound quality. Adjust vertical hold control to vertically synchronize the picture. Adjust the contrast control to slightly less than normal.

Adjust B_1 until the blanking bar, which may appear in the picture, moves to the right and off the raster. If ripples occur in the raster turn B_1 in a clockwise direction until the unstable condition is removed. The length of this adjustment screw in its correct position is usually about 1/2 inch beyond the bushing.

Turn horizontal hold control fully counter-clockwise and adjust B_2 clockwise until picture fails to synchronize. Now slowly turn B_2 counter-clockwise to the point where the picture synchronizes. Readjust B_1 so that the left side of the picture is close to the left side of the raster but does not fold over.

Turn the horizontal hold control fully clockwise. The right side of the picture should be close to the right side of the raster, but should not fold over. If it does, readjust B_1 .

Momentarily remove the signal. When signal is restored, the picture should fall into synchronization. If it does not, turn B_2 counter-clockwise until picture falls into synchronization.

Turn horizontal hold control fully counter-clockwise. Picture should fall back into synchronization after momentary removal of the signal.

If picture fails to synchronize after momentary removal of the signal at both extremes of the horizontal hold control, there may be insufficient pull-in range. However, if picture will pull in through 3/4 of the hold control range, operation should be satisfactory as excessive pull-in is objectionable. Excessive pull-in makes the control circuits more sensitive which may result in their being triggered by noise pulses. Also the vertical synchronizing and equalizing pulses may cause a bend in the upper part of the picture.

LINEARITY ADJUSTMENTS

HEIGHT AND VERTICAL LINEARITY ADJUSTMENTS.

Adjust the HEIGHT control until picture fills mask vertically (6 3/8 inches). Adjust VERTICAL LINEARITY for best linearity top to bottom. Readjust the HEIGHT control for proper height. The two controls are interacting and adjustment of one will require readjustment of the other. Adjust vertical centering to center picture vertically.

WIDTH AND HORIZONTAL LINEARITY ADJUSTMENTS.

Turn the horizontal peaking control clockwise as far as possible without crowding the right side of picture. This provides maximum voltage to picture tube second anode. Adjust

width control until raster fills the mask horizontally (8 1/2 inches). Adjust the horizontal linearity control until picture is symmetrical left to right. (It may be necessary to slightly readjust the horizontal peaking control). Adjust the horizontal centering control to center picture horizontally.

If continued adjustments of the peaking, width and linearity controls fail to give proper linearity, it may be necessary to move the tap on R123 which is located in the high voltage compartment. After this tap is moved, it will be necessary to readjust the peaking, width and linearity controls.

DISASSEMBLY INSTRUCTIONS

1. Remove eight push-on type control knobs.
 2. Remove nine screws holding back cover. Remove back cover.
 3. Remove speaker plug from speaker.
 4. Remove five 7/16" hex head bolts holding chassis.
 5. Remove two wood screws from rear of picture tube top cover. Remove cover.
 6. Remove two wood screws holding picture tube front cover. Remove cover.
 7. Loosen two screws holding each clamp at top of picture tube. Pull picture tube out front of cabinet.
 8. Remove chassis by pulling out back of cabinet.
 9. Remove four 1/4" hex nuts holding speaker. Remove speaker.
- CAUTION: REMOVE PICTURE TUBE BEFORE REMOVING CHASSIS.