

INSTALLATION INSTRUCTIONS

# ***Master***

**REMOTE CONTROL**



---

**COASTWISE ELECTRONICS CO.**

**Los Angeles 12**

**Calif.**

---

---

The MASTER Remote Control enables television viewers to change their sets from one channel to another, as well as adjust sound and picture, without the necessity of getting up and going to the set itself.

Model 501-D operates only with Intercarrier sets such as General Electric, Zenith, Motorola, Hallicrafter, Admiral, Stewart-Warner, TeleTone, Kaye Halbert, Capehart-Stromberg-Carlson and certain Philco, Hoffman and Packard Bell Receivers. (IMMEDIATE DELIVERY.)

For conventional sets such as RCA, certain Hoffman, Packard Bell and Philco receivers, our Model 510-B will be available AFTER JANUARY 1, 1951.

**NOTE TO TV TECHNICIANS**—Channel 6 on the TV set must have been aligned. If this has not been done at the Factory, it is suggested that Channel 6 be aligned at 85 MG. The Output Frequency of the MASTER Remote Control is 85 MC.

**TO HOOK UP MASTER CONTROL:** (1) Disconnect Antenna Lead from TV Set and connect to back of the MASTER Remote Control on terminals marked A N T. (2) Connect desired length of Antenna Ribbon between Antenna Posts on the TV Set and the Terminals on the rear of MASTER Remote Control marked R E C. (3) Plug in AC line of the MASTER Remote Control and the unit is now ready for use. (This Unit does not operate on D. C. Current.) Turn TV Set ON. An AC Socket is provided on the back of the MASTER Remote Control, in the event it is desired to plug the TV Set direct to the MASTER Remote Control. This provides the facility of turning the TV Set ON & OFF at the MASTER Remote Control.

(4) Turn Channel Selector Switch on TV Set to Channel 6.

(5) A. Set the Channel knob on the MASTER Remote Control to the weakest high band station in your area. (7, 9, 11 or 13).

B. Turn PICTURE knob on MASTER Remote Control until best picture is obtained.

C. Turn SOUND knob on MASTER Remote Control until best sound is obtained.

D. Return to TV Set and adjust Fine-Tuning, Brightness and Contrast Controls for best reception. Once this is done, it will not be necessary to re-adjust any of these controls regardless of how often you change Channels with your MASTER Remote Control.

---

---

---

---

---

---

---

---

## **IMPORTANT**

YOUR CUSTOMER SHOULD BE CAUTIONED THAT AFTER INSTALLATION HAS BEEN MADE, THE CONTROLS ON THE TV SET SHOULD NOT BE MOVED. However, if this does happen, the customer needs only to follow these three simple steps to retune the TV set.

1. Turn Channel Selector on TV set to Channel 6.
2. Adjust fine tuning knob on TV set to best picture and sound.
3. Adjust sound control on TV Receiver to desired level.

**NOTE TO TECHNICIAN**—In order to insure customer familiarity with Tuning procedure, it is suggested that the TV set be detuned after installation and under your supervision be retuned by the customer according to the above three steps.

---

---

---

---

---

---

# Guarantee

(MATERIALS and WORKMANSHIP)

We guarantee this MASTER REMOTE CONTROL to be free from defects in materials or workmanship under normal use. Our obligation under this warranty is limited to repairing or replacing this unit, provided it is returned, transportation prepaid, to our factory within ninety (90) days after date of sale.

This guarantee expressly does not cover vacuum tubes of any description which are shipped within or as accessories to any instrument. (Tubes are guaranteed by the tube manufacturer.)

Guarantee will not apply to any unit which has been tampered with or which has the serial number altered or removed, or which has been subjected to negligence, misuse or accident.

**COASTWISE ELECTRONICS CO., INC.**

130 NORTH BEAUDRY AVENUE  
LOS ANGELES 12, CALIFORNIA

Model No. 501-D

Model No. 510-B