

TELEVISION Service Manual

PUBLISHED BY RADIO COLLEGE OF CANADA, TORONTO

1966 Supplement No. 70

INDEX

CHECK YOUR TUBE INVENTORY

A list of tube types used in receivers covered by this supplement appears on page 108.

ADMIRAL

Chassis	Page
G4-1X, Y, Z All data	47, 48
G4-2X, Y, Z All data	47, 48
G4-3X, Y, Z All data	47, 48
G4-4X, U All data	49, 50
G6-2X All data	53, 54
G6-2Y, Z Circuit	53, 54
G6-2Y, Z Tuner circuits	2
G6-3X All data	55, 56
22C5AX (Radio) All data	51, 52

Model

466C1, CU1 See G4-4X	P2110 See G4-1X
CG3301 See G4-4X	P2119 See G4-1X
CG3311 See G4-4X	P2127 See G4-1X
CG3321 See G4-4X	P2134 See G6-2X
CG3381 See G4-4X	P2139 See G6-2X
CGU3301 See G4-4X	P2147 See G6-2X
CGU3311 See G4-4X	P2149 See G6-2X
CGU332 See G4-4X	P7518 See G4-1X
CGU3381 See G4-4X	PS2134 See G6-3X
LG3331 See G4-4X	PS2139 See G6-3X
LG3391 See G4-4X	PS2147 See G6-3X
LGU3331 See G4-4X	SMG3321 See G4-4X
LGU3391 See G4-4X	SMGU3321 See G4-4X
P2101 See G4-1X	

CANADIAN GENERAL ELECTRIC

Model

95T55Z See M638 in Supp. #65.
95T56Z See M638 in Supp. #65.
(These two models use picture tube 19DVP4).

ELECTROHOME

Model	Page
Ambassador A-092 Circuit	57, 58
Ambassador A-092 Tuner circuit	3
Ambassador AU-093 See A-092.	
Normandy A-090, AU-091 See Ambassador.	
Pacifican A-094, AU-095 See Ambassador.	

FLEETWOOD

Model	Page
F165A Circuit	61, 62
F165A Alignment	8, 9, 10
F165A Layout	10
F165A Coil identification	9
F165B, C etc. See F165A.	
2101 Circuit	63, 64
2101 Alignment	11, 12
2101 Layouts	11
2102 See 2101.	

HAVE YOU THE CURRENT ISSUE OF THE MASTER INDEX? YOU'LL FIND IT SPEEDS UP YOUR WORK.

MARCONI

Chassis	Page
TV-721-1 Circuit	65, 66
TV-721-1 Alignment	13, 14, 15
TV-721-1 Layouts	15
Model	
340K23 See TV-721-1.	
341K23 See TV-721-1.	

PHILCO

Chassis	Page
16N35 Circuit	67, 68
16N35 Tuner circuit	19
16N35 Alignment	16, 17, 18
16N35 Layout, Voltages, resistances	69, 70

Model

5683 See 16N35.
5680 See 16N35.
6002 See 16N35.
6006 See 16N35.
6008 See 16N35.

RCA-VICTOR

COLOR

CTC17X Circuit	44, 45, 46
CTC17X Tuner circuit	25
CTC17X Remote control circuits	38, 39
CTC17X Alignment:	
General	20, 21
KRK120 Tuner	26, 27
KRK124 Tuner	22 to 25
Sound IF and demodulator	28
Picture IF transformer	29
Picture IF sweep alignment	30, 31
Horizontal deflection	32
Chroma bandpass	33
Color AFPC (shop)	34, 35
Color AFPC (field)	36, 37
Waveforms	40, 41
UHF Alignment fixtures	43
CTC17X Layout	42

Model See Cross-index on page 20.

RCA-VICTOR

MONOCHROME

Chassis	Page
CT1911B See CT1911A in Supp. #58.	
CT1914A Circuit	71, 72
CT1914A Radio data	85
CT1914A Other data see CT2308A in Supp. #60.	
CT2312A, B Circuit	73, 74
CT2312A, B Tuner circuit	91
CT2312A, B Alignment	86 to 90
CT2312A, B Layout	88
CT2312A, B Coil identification	90
CT2313A Circuit	76, 77
CT2313A Other data see CT2312A, B.	

Model

TC3631 See CT2312A.	TC3638 See CT2312A.
TC3632 See CT2312A.	TC3639 See CT2312A.
TC3633 See CT2312A.	TC3640 See CT2313A.
TC3636 See CT2312A.	TC3641 See CT2312A.
TC3637 See CT2312A.	TC3642 See CT2312A.
TP9519 See CT1911A in Supp. #58.	TMT9503 See CT1914A.
TP9524 See CT1911A in Supp. #58.	
TS9643, S See CT2312B.	
TS9644 See CT2312B.	
TS9645 See CT2312B.	

SIMPSON'S-SEARS

Chassis	Page
C817.13204 Circuit	77, 78
C817.13204 Tuner circuit	95
C817.13204 Alignment	92 to 94
C817.13204 Coil identification	95
C817.13300 Circuit	79, 80
C817.13300 Tuner circuit	99
C817.13300 Alignment	96, 98
C817.13300 Layout	97
C817.13300 Coil identification	99

Model

13461B See C817.13204.
13600 See C817.13300.

VIKING

Model	Page
TCD-341 Circuit	59, 60
TCD-341 Tuner circuit	7
TCD-341 Alignment	4, 5, 6
TCD-341 Layouts	6, 7
TCD-341 Coil identification	6
TCD-342 See TCD-341.	
TCD-343 See TCD-341.	
TCD-346 See TCD-341.	
TCD-347 See TCD-341.	
TMD-344 See TCD-341.	
TMD-345 See TCD-341.	
TRPD-348 See TCD-341.	
TRPD-349M See TCD-341.	
VPC409, U See Philco 16N35.	

WESTINGHOUSE

Chassis	Page
X-2487-21 Circuit	81, 82
X-2487-21 Tuner circuit	101
X-2487-21 Alignment	102, 103
X-2487-21 Layout	100
X-2487-21 Resistance chart	104
X-2487-21 Coil identification	105
X-2487-23 See -21.	
X-2487-25 See -21.	
X-2487-31 See -21.	
X-2487-32 See -21.	

Model

KV921/922 See X-2487-21.
P3066A See X-2487-21.
P3080/81 See X-2487-21.
P3080A/81A See X-2487-21.
RS923 See X-2487-21.
T100 See X-2487-21.

ZENITH

Chassis	Page
14N31 Circuit	83, 84
14N31 Layouts	106, 107

RCC
TELEVISION
Supplement
No. 70

ADMIRAL G4-4X, U

49


L201	Interstage	72C208-6	L307	R.F. 80 MC (Orange)	73B31-4
L202	Quadrature Sound	72K16-1	L308	Peaking (Black)	73M10-10
L301	47.25 MC Trap	72C132-65	L309	Peaking (White)	73M10-9
	or	72C296-2	L310	Peaking (Brown)	73M10-1
L302	I.F. Input	72C132-67	L311	Filament Choke (Red)	73X37-2
	or	72C296-2	L312	Filament Choke (Red)	73X37-2

RUN CHANGES—


① Start of production

② R421 added to center vertical hold range


VHF TUNER 94M27-2




VHF TUNER 94M27-3



VHF - UHF ASSEMBLY 94M28-1



NOTES—
VOLTAGES MEASURED WITH VHF LINE NO SIGNAL CONTRAST
AND BRIGHTNESS MAXIMUM. ALL OTHER CONTROLS AT NORMAL SETTING.
WAVEFORMS MEASURED WITH WIDE BAND OSCILLOSCOPE. MEDIUM SIGNAL
INPUT CONTROLS AS ABOVE.
ARROW THROUGH VARIABLE AMP ON CONTROLS INDICATES CLOCKWISE
ROTATION AND MAXIMUM SETTING.
— CHASSIS GROUND
P — PART NOT MOUNTED ON CIRCUIT BOARD
— VOLTAGE WILL VARY WITH SETTING OF CONTROLS
— CABBET GROUND



L401	Horizontal Osc.	94M15-7	T301	I.F. Interstage	72Z222-4
L402	R.F. Choke	73B31-11	T302	Last I.F.	72B261-2
L403	Spook Choke	73C37-19	T303	Sound Take-Off & Trap	72C185-2
L501	R.F. Line Choke	73B31-1	T401	Vertical Output	79M4-15
L502	Filter Choke	74D18-53	T402	Deflection Yoke	94N22-5
T201	Audio Output	79M9-28	T403	Horizontal Output	79N15-3

